



* Remove R7 & C5 and install jumper.
 # Sw1 located on Tone Conrtol

S.T.A.C.		
Kay Model 703-C Safety Mod		
Pete Mitcheltree	Rev 1.0	Page 1
	9/3/2015	