



**PPIMV mod**

1. Remove two 470K grid resistors.
2. Relocate .0047µF cap to pots.
3. Connect PPIMV ground to PA Gnd.
4. Use shielded cable if wires are long.