



Flip board over (top to bottom) and install turrets on the side that was originally the bottom side.

Nothing on this panel