



Alternate connection for INT pot...
Connect hot side of pot to V3 pin 7.

Hoffman Amplifiers Princeton Reverb With Trem-O-Nator mod

Hoffman Princeton Reverb

