



- 1) Voltages as measured with all tubes installed
- 2) Values in parenthesis are values used in Metropolis JTM45

<b>RoadShow</b>		
<b>Dual 2203-JTM45</b>		
Bill Anderson	Rev 1.0 12/04/2022	Power Section