


Fx Loop

From INSIDE Amp

~~With all elements~~



When plug is in Jack 1, it breaks the signal, sending it to Fx. When switch is closed (i.e. Jack plug removed), signal goes out the switch leg to its destination.