

FENDER PA 135 VOCAL SOUND SYSTEM

735 W Rms (3/28/70)

PARTS PRICE LIST (REVERB MODEL)

013341	7025/12AX7A Tube	4.50	026730	Diode 1 Amp 800V	2.00
023531	12AT7 Tube	5.00	024604	Knob	1.00
023556	6L6GC Tube	7.00	011349	Knob (-5 +5)	2.50
			014334	Back Plate	6.50
013692	Power Transformer	70.00	014336	Control Plate	12.00
013691	Output Transformer	48.00	010766	AC Power Cord	6.00
022921	Reverb Transformer	7.50	007565	Power Cord Strain Relief Bushing	1.00
010023	Ground Switch (SP-DT)	2.00	014493	Cabinet w/hardware (PA Top)	80.00
010437	Bias Control (10K)	2.00	014334	Rear Panel	6.50
010699	Output Jack	3.00	011231	Rear Panel Screw	.10
011028	Input Jack	3.00	012974	Grill Cloth Frame w/hardware (Top)	10.00
021857	Vol/Treble/Bass Control (250K)	2.00	011655	Chassis Screw	.50
021873	Master Reverb Control (100K)	2.00	090662	Chassis Nut (Clip-On)	.10
021956	Phone Jack (Open)	1.50	021691	Bushing Strain Relief	.50
024042	Foot Switch	4.00	022491	Cable Clamp	.20
028167	Phone Plug Assy	2.00	022665	Ft Switch Cover	1.00
028421	Hum/Balance Control (100 Ohm)	2.00	024000	Plug-Phono	.50
037960	On-Off-Stand-by Switch (SP-ST)	2.00	022012	Switch Hex Nut	.10
013404	Rev. Control 250K W/SW	3.00	022293	Switch Washer	.10
			024695	Amp Corner	1.00
008167	100K Ohm 1 Watt	1.00	022103	Amp Corner Screw	.50
021519	1K Ohm 1 Watt	.50	024752	Chassis Strap-Long	1.00
013765	30K Ohm 20 Watt	2.00	025403	Amp Handle	2.00
011252	1.5 Meg. 1/2 Watt	.50	022244	Amp Handle Screw	.50
021170	100 Ohm 1/2 Watt	.50	021972	Amp Handle Tee Nut	.10
021188	470 Ohm 1/2 Watt	.50	025395	Amp Handle Cap	.50
021196	820 Ohm 1/2 Watt	.50	041046	Glide Assembly	.50
021212	1.5K Ohm 1/2 Watt	.50	026625	Glide Assembly Screw	.10
013764	2.7 Ohm 10 Watt	.50	025163	Vinyl-Black (Requires 1 Yd.)	10.50 Yd
021220	2.2K Ohm 1/2 Watt	.50	064063	Reverb Pan	40.00
012388	22K Ohm 1 Watt	.50	071415	Reverb Output Transducer	7.00
021295	22K Ohm 1/2 Watt	.50	071423	Reverb Input Transducer	7.00
021311	47K Ohm 1/2 Watt	.50	031930	Cord Assembly (27 In)	2.50
006138	33K Ohm 1/2 Watt	.50	033282	Cord Assembly (36 In)	3.00
021345	100K Ohm 1/2 Watt	.50	021956	Jack, Line/Recording	1.50
021352	470K Ohm 1/2 Watt	.50			
021238	2.7K Ohm 1/2 Watt	.50	012967	Grill Frame w/Hdw Spk. Encl.	25.00
021402	470 Ohm 1 Watt	.50	011194	Speaker-8" Fender (32 Ohm)	24.00
021410	4.7K Ohm 1 Watt	1.00	011162	Cabinet, w/hardware	144.00
021493	220K Ohm 1/2 Watt	.50	011164	Rear Panel	23.00
051136	.39K Ohm 1/2 Watt	.50	011231	Rear Panel Screw	.10
065805	270K Ohm 1/2 Watt	.50	012449	Grill Cloth Black	19.00 Yd
065771	120K Ohm 1/2 Watt	.50	011168	Vinyl-White (Requires 1 Yd.)	12.00 Yd
070136	1.2K Ohm 1/2 Watt	.50	025163	Vinyl-Black (Requires 2 Yd.)	10.50 Yd
073502	270 Ohm 1/2 Watt	.50	011879	Glide Assembly	.50
090456	33K Ohm 1/2 Watt	.50	084699	Glide Assembly Screw	.50
021204	1K Ohm 1/2 Watt	.50	011185	Bracket, Speaker Cord	3.00
			022228	Speaker Screw	.10
012754	.047 x 600V	1.20	015826	Screw, Bracket	.10
001972	.047 Mfd x 600V	1.50	021964	Hex Nut, Bracket	.10
004026	22 Pfd x 1KV	1.50	012030	Amp Cord Assembly (25 ft.)	9.00
004513	.022 Mfd x 600V	1.00	067496	Amp Plug Assembly	2.00
009512	25 Mfd x 25V	1.00	022673	Amp Plug Cover	.10
007029	.00022 Mfd x 1KV	.50	021626	Phone Jack (Open)	2.00
010543	.01 Mfd x 600V	1.00	016352	Hex Nut-Jacks	.10
010641	750 Mfd x 3V	1.20	022368	Lock Washer-Jacks	.10
010542	.0047 Mfd x 600V	1.50	031153	Flat Washer-Jacks	.10
013638	220 Mfd x 285V	4.50	011901	Retainer Cup	.50
010992	560 Pfd x 3KV	1.00	011160	Side Panel White	11.50
020842	.0005 Mfd x 1KV	1.00			
012044	.0033 Mfd x 1KV	1.00			
020883	.00001 Mfd x 1KV	1.00	011756	HF5 Projection Horn	
020958	.005 Mfd x 1KV	1.00	975168	Horn 8 Ohm	59.00
020982	20 Mfd x 500V	3.00	011168	Horn Diaphragm	12.50
021022	.1 Mfd x 200V	1.50	011722	Vinyl-White (Requires 1 Yd.)	12.00 Yd
023257	.002 Mfd x 1KV	.50	011763	Cabinet, w/hardware	48.00
069724	.0001 Mfd x 100V	1.00	011231	Rear Panel	5.00
014122	70 Mfd x 100V	3.00	011762	Rear Panel Screw	.10
			012267	Rear Plate	6.00
021642	Pilot Light Lamp (#47)	.50	012267	Circuit Breaker	3.00
021741	Pilot Light Holder	.70	007235	Resistor-150 Ohm 7 Watt	.60
031625	Pilot Light Collar Nut	.50	011766	Resistor-25 Ohm 10 Watt	1.50
010823	Pilot Light Dress Washer	.70	023463	Capacitor-4 Mfd x 350V	3.00
032219	Pilot Light Collar	.70	021956	Phone Jack (Open)	1.50
025718	Pilot Light Jewel	1.50	022384	Phone Jack Lock Washer	.10
021576	AC Socket	3.00	016352	Phone Jack Hex Nut	.10
013737	4 Amp Fuse (Slo Blo)	1.20	017038	Switch Slide	2.00
021527	Fuse Holder	2.00	067496	Amp Plug Assembly	2.00
025866	Tube Retainer Ring	.40	022673	Amp Plug Assembly Cover	.10
023598	Tube Shield	1.00	069385	Crossover Assembly Screw	.10
023606	9 Pin Tube Socket	1.00	069393	Crossover Assembly Nut (lock)	.10
023580	8 Pin Tube Socket	1.00	011907	Piggy Back Cord Assembly	6.00
021535	Rectifier (Diode) 1 Amp	2.00	025163	Vinyl-Black (Requires 1 Yd.)	10.50 Yd
016436	Lock Washer, Control	.50			
			022764	Export Models Only	
			013830	Power Transformer 100 Watt	
				Power Transformer 135 Watt	

