

Ampeg B-12-XY													
Tube Number	Tube Type	Pin No. 1	Pin No. 2	Pin No. 3	Pin No. 4	Pin No. 5	Pin No. 6	Pin No. 7	Pin No. 8	Pin No. 9	Pin No. 10	Pin No. 11	Pin No. 12
1	7027A	---	---	513.1	460.1	---	-51.3	---	0	---	---	---	---
2	7027A	---	---	513.5	460.1	---	-51.3	---	0	---	---	---	---
3	7199	245.9	146.1	58.6	---	---	2.0	0	115.5	<u>102.8</u>	---	---	---
4	6SL7	0	170.9	2.2	0	111.7	1.1	---	---	---	---	---	---
5	6SN7	-.2	112.9	0	0	98.7	2.9	---	---	---	---	---	---
6	6SN7	-.5	109.2	0	0	97.3	3.0	---	---	---	---	---	---
7	6D10	---	252.5	37.0	1.4	254.0	22.5	0	---	0	46.2	0	---
8	6D10	---	116.4	2.7	3.1	115.6	2.3	0	---	0	167.8	0	---
9	7591	---	---	452.6	383.7	16.2	0	---	---	---	---	---	---
10	5AR4	---	---	---	417.1AC	---	417.1AC	---	513.3	---	---	---	---

5. 38vAC Filament
6. 33vAC Filament
-51.9vDC Bias