Fender AB763 Twin Reverb Voltage Chart

All voltages are taken from the official Schematic	Normal Channel Stages 1&2	Tremolo Channel Stages 1&2	Reverb Driver	Reverb Recovery & stage 3	Tremolo Oscillator	Phase Inverter	Beam Power Tube	Beam Power Tube	Beam Power Tube	Beam Power Tube
Tube Position	**V1**	**V2**	**V3**	**V4**	**V5**	**V6**	**V7**	**V8**	**V9**	**V10**
	12AX7	12AX7	12AX7	12AX7	12AX7	12AX7	6L6GC	6L6GC	6L6GC	6L6GC
Pin 1	**260 VDC**	**250 VDC**	**440 VDC**	**275 VDC**	**300 VDC**	**245 VDC**				
Actual										
Pin 2	VDC	VDC	VDC	VDC	VDC	VDC	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**
Actual										
Pin 3	**2.0 VDC**	**2.0 VDC**	**8.6VDC**	**2.0 VDC**	**2.0 VDC**	**100 VDC**	**460 VDC**	**460 VDC**	**460 VDC**	**460 VDC**
Actual										
Pin 4	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**458 VDC**	**458 VDC**	**458 VDC**	**458 VDC**
Actual										
Pin 5	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**--52 VDC**	**--52 VDC**	**--52 VDC**	**--52 VDC**
Actual										
Pin 6	**270 VDC**	**240 VDC**	**440 VDC**	**280 VDC**	**380 VDC**	**235 VDC**	**460 VDC**	**460 VDC**	**460 VDC**	**460 VDC**
Actual										
Pin 7	VDC	VDC	**8.6 VDC**	VDC	VDC	VDC	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**
Actual										
Pin 8	**2.0 VDC**	**2.0VDC**	**8.6 VDC**	**2.0 VDC**	**12 VDC**	**100 VDC**				
Actual										
Pin 9	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**	**3.1 VAC**				
Actual										